


Anti-syphon unit with non-return valve and hose connectors



In addition to avoiding vacuum by the main drainpipe, it prevents dirty water from returning into the washing machine or dishwasher;

This is the device which guarantees a maximum security.

During assembly, the embossed arrows on the valve body must point towards the water flow direction from the domestic appliance to the drain.