


Anti-syphon unit



A polypropylene air intake which prevents any risk that the washing machine or dishwasher continuously drains due to the vacuum effect caused by the drainage pipe.

This valve must be inserted between the drain saddle and the non-return valve. **(see also “fast flow drain kits”).**

During assembly, the embossed arrows on the valve body must point towards the water flow direction from the domestic appliance to the drain.